



#grsriflestocks

## HEIGHT ADJUSTABLE RECOIL PAD ASSEMBLING



01.  
Push the recoil pad button  
all the way in. (If you have  
the new adjustment system:  
loosen with an Allen  
wrench first.)



02.  
Remove recoil assembly



03.  
Make sure your Height  
Adjustable Recoil Pad set  
is complete.



04a.  
Disassemble the metal plate  
from the GRS Limbsaver.



04b.



05.  
Place the metal nuts in  
position.




06.  
Place the Recoil assembly on  
top of the height adjustment  
metal plate.



07.  
SOFT Locktite no. 222  
on bottom (small) screw.




## HEIGHT ADJUSTABLE RECOIL PAD ASSEMBLING




08.  
Wipe off to leave only  
a thin layer.



09.  
Assemble bottom  
(small) screw.




10.  
SOFT Locktite no. 222  
on top (larger) screw.




11.  
Wipe off to leave only  
a thin layer.



12.  
Assemble top  
(larger) screw.



13.  
Tighten.



13b.  
Tighten (different view).



14.  
Function check.




#grsriflestocks

## HEIGHT ADJUSTABLE RECOIL PAD ASSEMBLING



15.  
Slide to lower position.



16.  
Assemble pad.



17.  
Ready for mounting onto  
stock.



18.  
Reassemble.



20.  
You're done.  
Have a great day!